

AireShare™ Transfer Fan Specification Sheet

Model AS1



| Job Name:   | Equipment Rep:  |  |  |  |
|---|---|--|--|--|
| Contractor:   | Tjernlund Contact:  |  |  |  |
| Arch./Engr.:  | Date:   |  |  |  |
| <b>Description:</b><br>Low sone, cross-flow blower quietly moves conditioned air through<br>the wall cavity from one room to an adjacent room. Design allows  | <b>Typical Specification:</b><br>Device shall be Tjernlund Model AS1.               |  |  |  |
| for intake and diffuser to be located high or low or almost directly<br>across from one another.  | Device shall move air using a vibration isolated, cross-flow blower.                |  |  |  |
| Blower Grille:<br>22 gauge aluminized steel. Washable powder coat with satin  | Diffuser shall be equipped with a built-in turning vane.                            |  |  |  |
| white finish. Can be repainted.   | Diffuser shall have a discharge deflector with an angle of 15° to the horizontal.   |  |  |  |
| Diffuser:   |   |  |  |  |
| 20 gauge aluminized steel with attached adjustable-fit flanges.<br>Unexposed built-in turning vane. Washable powder coat with satin   | Device shall have a sound level no greater than 1.5 Sones.                          |  |  |  |
| white finish. Can be repainted.   | Power consumption of device shall be no greater than 30 watts.                      |  |  |  |
| Blower:   |   |  |  |  |
| Cross-flow blower. Factory balanced for quiet operation.  | Device shall have no power cord exposed outside the wall in which it is installed.  |  |  |  |
| Motor:  |   |  |  |  |
| C-Frame motor. Bearings designed for 32,000 operating hours.  | Device shall be Listed in the USA to ANSI/UL 507 and in Canada to CSA C22.2 #113-M. |  |  |  |
| Supply Power:   |   |  |  |  |
| Installer supplied to the AS1 electrical box. Industry standard 7/8" electrical knockouts located on the top and bottom for ease of installation. Add a 120 VAC wall switch or thermostat to turn on/off. |   |  |  |  |

#### Installation Notes:

When installed between metal studs all knockouts should be plugged or sealed.

Device shall NOT be installed in an exterior wall.

Device shall NOT be installed in a fire-rated wall.

### Warranty:

One (1) year material and workmanship.

## Specifications:

|     |     |     |    |      | Sones, dB  |    | INTER TEAT |
|-----|-----|-----|----|------|------------|----|------------|
| AS1 | 120 | .50 | 25 | 1800 | 1.15, 42dB | 75 |            |
|     |     |     |    |      |            |    | c          |

Tjernlund Products, Inc. • 1601 Ninth Street • White Bear Lake, MN 55110 • (651) 426-2993 • (800) 255-4208 • FAX (651) 426-9547 • www.tjernlund.com

# **Model AS1 Dimensions**

# AS1 Diffuser

